BRAVILOR BONAMAT

SPRSo

TECHNICAL MANUAL



Technical manual - English

Original document by manufacturer
version 1.2 | 2025-12-09

All rights reserved.
No part of this document may be copied and/or published by means of printing, photocopying, microfilming or by any other means whatsoever without the prior written consent of the manufacturer. This also applies to the included drawings and/or diagrams.
The information in this document is based on data that was available at the time the design, the material characteristics and the operating methods were published, meaning that this document is subject to change.
The original instructions for this manual have been written in English. Other language versions of this manual are a translation of the original instructions.
For this reason, the instructions are merely a guideline for the installation, maintenance and repair of the machine displayed on the front cover.
This document applies to the standard version of this machine.
The manufacturer therefore declines all liability for any damage arising from specifications that deviate from the standard version of the machine delivered to you.
This document has been compiled with the utmost care. However, the manufacturer cannot be held liable for any errors it contains or the consequences thereof.

BRAVILOR BONAMAT

Table of contents

1. Special functions 1
1.1 Water system calibration 3
1.2 Grinder calibration 6
2. Spare parts replacement 10
2.1 Brand name buckle and control panel 10
2.2 Outlet 11
2.3 Open right side panel 12
2.4 Remove back panel 13
2.5 Remove fan 13
2.6 Remove grinder 14
2.7 Remove the water counter/safety switches 15
2.8 Remove I/O board 16
2.9 Remove power board 16
2.10 Remove flash heater 17
2.11 Remove pump 18
2.12 Remove valve set 19
2.13 Remove brewer motor 21
2.14 Hose positions 22
3. Beverage profiles 23
3.1 Profile 1: small volumes / strong coffee 23
3.1.1 Selectable volume - small 23
3.1.2 Selectable volume - medium 24
3.1.3 Selectable volume - large 24
3.2 Profile 2: average volumes / regular strength 25
3.2.1 Selectable volume - small 25
3.2.2 Selectable volume - medium 25
3.2.3 Selectable volume - large 26
3.3 Profile 3: large volumes / regular strength 27
3.3.1 Selectable volume - small 27
3.3.2 Selectable volume - medium 27
3.3.3 Selectable volume - large 28
4. Software update instructions 29
5. Troubleshooting 31
5.1 Warning messages 31
5.2 Error messages 33
5.3 Other problems 35

General

- ► *Always read the safety instructions (700.403.347).*
  To avoid possible damage, these safety instructions must be read, understood and followed.
- ► *Manuals are subject to change, scan the QR code to retrieve current information.*

1. Special functions

By using a ‘secret key combination’ special features can be activated.

1a



Standby mode:

- press and hold the button start for 5 seconds
- necessary flushes will be done
- the “goodbye” screen is turned off and only the start button is flashing slowly

► *The standby mode is a function which can be enabled for energy saving.*

► *Press the start button to end the standby mode.*

1b



Demo mode on/off:

- press and hold the button combination ☰ and start for 10 seconds

► *The demo mode is a function which can be enabled for marketing purposes.*

► *Switch off the Sprso to end the demo mode.*

1c



Child lock on/off:

- press and hold the button combination ‹ and › for 5 seconds

► *This function is to lock (and unlock) all controls to prevent accidental dosing.*

1d



Reset the cleaning brewer counter:

- press and hold the button for 10 seconds in this screen until the maintenance menu appears

► *The counter that triggers the clean brewer message is reset.*

1e



Reset the descaling counter:

- press and hold the button for 10 seconds in this screen until the maintenance menu appears

► *The counter that triggers the descale message is reset.*

1.1 Water system calibration

In this menu the water system can be calibrated.
With calibration the volume of the water is determined for a defined flow and time.
When finished the measured volume must be filled in.

► *The water system calibration is used to adjust the differences between the actual water delivery of the Sprso and the indicated amount.*

Necessities:
• measuring cup (with fine scale)



1.1a

Water system calibration:
• go to the program menu
• press and hold the button combination and for 5 seconds



1.1b

Calibration water system:
• press **start** to confirm



1.1c

Step 1: preparation
• make sure that you have all necessities
• press > to go to the next step

1.1d



Step 2: preparation
- follow the instructions on the screen
- press **start** to begin the calibration

1.1e



Step 3: dosing hot water
- wait for the next screen

1.1f



Step 4: measure
- read the dosed water
- press > to go to the next step

1.1g



Step 5: measure
- press < or > to enter the measured volume
- press **start** to confirm

1.1h



New water volume is saved:
- wait for the next screen
- exit the menu by pressing

1.2 Grinder calibration

The grinder calibration will affect every coffee related beverage.

Necessities:
- coffee beans
- digital kitchen scales

1.2a



Grinder calibration:
- go to the program menu
- press and hold the button combination and for 5 seconds

1.2b



Calibration grinder:
- press **start** to confirm

1.2c



Step 1: preparation
- make sure that you have all necessities
- press > to go to the next step